

Zebex 3052 2D setovanje



HID Keyboard Emulation

CR/LF (Enter) posle skeniranja:



<DATA> <SUFFIX 1>

Automatsko okidanje



Presentation Mode
(Default for scan module)



Scan Suffix 1

Rucno okidanje



Level

(Default for handheld/hands-free scanner)



6



0



5



8