

Fiscal printers in Serbia - Quick guide -

Fiscal printer INT RASTER FP-600 you can connect to PC only through RS232 cable. If PC doesn't have RS232, you can use "USB to RS232" adapter (about 15 EUR).

There is 3 ways to print fiscal receipts/reports/free text on FP-600:

1. Direct communication with printer - sending specific commands to serial port– please find "INT RASTER FP-600 Programming manual" in attachment.
This way of communication is not easy – for each command you must send whole HEX string to serial port, calculate checksum, read answers from printer etc.
This detail is explained in Programming manual.
2. Using "link" application – "FprintWin" – this application is resident in memory, you just need to create TXT file and put the file in OUTGOING folder.
FprintWin process this TXT file and sends to fiscal printer. Answer from printer (successfully or not, paper missing or other error code) FprintWin puts into INCOMING folder, also like TXT file.
You can read this file from your application and see what happen with document after sending to printer.
This application (english) you can download here: www.intraster.rs
Command description are between pages 66-76 in PDF Manual for Serbia.
3. Using DLL library (from other Serbian software company) and call printer functions from your application in Delphi, VB or C/C#.
For price and more details please ask.

P.S. If your application works with some fiscal printer in other country, maybe you have to made minor changes. Please let me know on which way your application communicate with fiscal printer.

If you have any question, please do not hesitate to ask.

Best regards,



Dejan Doncic
Technical director

Tel. +381(0)60 011 2150
+381(0)11 6564 253

Mail: dejan.doncic@intraster.rs

Serbia - 11000 Belgrade – Tose Jovanovica 11
www.intraster.rs